



HIGH PERFORMANCE STROLLERS

# Soft Pram Accessory Assembly Instructions

**WARNING:** For support reasons, the Soft Pram is only compatible with the City Elite and City Classic single and double strollers.  
**WARNING:** Check that the pram body or seat unit attachment devices are correctly engaged before use.



**Inside the Box:**  
Soft Pram, 2 Carrying Straps,  
2 U-shaped brackets.

**1** Fold the opening of the Soft Pram back and secure each side with loop and toggle. Turn the Soft Pram over so the base is facing up. **2** Insert one U-shaped support bracket into the opening on the base of the Soft Pram so that the bottom of the U crosses the width of the Soft Pram. **3** Insert other U-shaped support bracket into second opening on the Soft Pram's base. Turn the Soft Pram over so that the opening faces up.



**4** On the left side of the Soft Pram, pull back the opening on the edge of the Soft Pram to expose the buckle opening (attached to the end of the U-shaped support bracket). Slide the buckle fork on the end of one of the carrying straps into the buckle opening until it clicks into place. **5** On the same side, slide the buckle fork on the other side of the carry strap into the second buckle opening. (NOTE: Do not cross over the Soft Pram with the carry strap.) **6** Repeat on the right side of the Soft Pram so that both carry straps are secured to the Soft Pram. (NOTE: A Velcro handle is attached to one of the carry straps for your carrying convenience.) **7** Recline the seat of your stroller to its near-flat position.



**8** Lay the Soft Pram in the reclined seat of the stroller. **9** Lift up the front end of the Soft Pram and un-velcro the square metal support bar from the bottom of the Soft Pram. **10** Lower the Soft Pram so that the metal support bar rests in the crease of the footplate. NOTE: If you are using the Soft Pram on the City Elite you can use the Elite's raised kicker to support the Soft Pram rather than the attached support bar. **11** Unsnap the safety straps from each other on the front of the Soft Pram. Wrap left hand strap around the frame just above the footplate. Snap into place and repeat on other side.



**12** On the left side of the Soft Pram, thread the Velcro strap behind the fabric and around the accessory mounting bracket. **13** Thread the Velcro strap through the D-ring. Tighten and secure. **14** Repeat on right side. The Soft Pram is now secured in the reclined seat of your stroller.